

MOLLE

TAILGATE PANEL

Installation Instructions

1. **TAILGATE INSTALLATION** -When installing the molle panel for the tailgate center the panel on the flattest part of the tailgate ***NOTE be sure not to position the panel too high because it will interfere with the back glass and you will have to drill more holes in your jeep than you need to.** Then mark the four holes on the tailgate.
2. Drill the holes using a 7/32 drill bit.
3. Tighten the screws down but be careful not to over tighten and strip them out, stainless steel is more brittle than regular steel and therefore, not as forgiving.
4. **FOLD DOWN TAILGATE** – Adjust the support straps so that your tailgate will lay flat, and also you may need to adjust them after you get your gear loaded onto the panel, also tighten the two bottom hinge bolts.