

OVERHEAD MOLLE PANEL

INSTALATION INSTRUCTIONS

1. Flop the soft top back or take the front two panels off the freedom hard top. Remove the plastic bezel on top of the inside of the windshield.
2. Place the rear of the overhead molle panel on top of the center speaker bar. Snug the front of the molle panel up to the rubber seal where the “tops” seal down to the windshield.
3. Mark the three holes and drill a 3/16” hole through the sheet metal. **NOTE: BE GENTAL AND TAKE YOUR TIME.**
4. Secure the front of the molle panel with the three screws provided. **NOTE: GO SLOW WITH THE SCREWS STAINLESS STEEL SCREWS ARE MORE BRITTLE THAN NORMAL STEEL.**
5. Secure the rear of the panel with the two zip ties provided.
6. Replace the plastic bezel onto the windshield. **NOTE: YOU MAY HAVE TO TRIM THE PLASTIC PIECE TO GET IT TO FIT UP TIGHT TO THE RUBBER SEAL.**
7. Put the top back into its original position and load the panel up with your molle to suit your needs.