

JL JEEP OVERHEAD MOLLE PANELS

- 1. “HARD TOPS”- Remove front freedom top panels, unbolt the rest of the hard top and slide it back about a foot.
“SOFT TOPS”- Flip the soft top back allowing you to access the top of your roll cage.**
- 2. “HARD TOPS”- Take note of the height location of your front two latch tabs above the rear view mirror. Remove those two tabs with a T30 bit.**
- 3. “HARD, SOFT TOPS”- Set the rear of the panel in place first. Then drop the front in place. You may have to slip the rubber seal out of the way to be able to drop the front of the panel down into place.**
- 4. Center the panel up, and drill a 1/8” hole for the screws, in the front slots and the rear holes.**
- 5. “HARD TOPS”- REMOUNT your hard top latch tabs in the same position they were before.**
- 6. Place rubber seal back if removed.**
- 7. Run the screws in and you are done.**